

Parlor Wash Set Up




Press F-8-↑ on the MPC to let milker arm down.



Unhook each of the units from the take off.



Place the milking units in the wash cups ensuring each inflation is well seated.




Press the shift change button on 1 MPC to put the system into wash mode (all MPC's should have On the display)



Close the plate cooler valve located in the utility room.



Manually run pumps to empty milk receivers. Stop 10 seconds after you hear a rumbling sound.



Close the bulk tank valve (1), turn the Hygenius off (2), Un hook the tank fill pipe from the bulk tank and move the pipe to the vertical position and connect to wash line (3), Connect the two pipes on the top of the wash vats (4), Start the wash cycle on the Hygenius (5), Monitor wash as it goes through each clyce to ensure it runs properly.